VPort P16-1MP-M12 Quick Installation Guide

Moxa IP Camera

Edition 2.0, February 2017

Technical Support Contact Information www.moxa.com/support

Moxa Americas:

Toll-free: 1-888-669-2872 Tel: 1-714-528-6777 Fax: 1-714-528-6778

Moxa Europe:

Tel: +49-89-3 70 03 99-0 Fax: +49-89-3 70 03 99-99

Moxa India:

Tel: +91-80-4172-9088 Fax: +91-80-4132-1045 <u>Moxa China (Shanghai office)</u>: Toll-free: 800-820-5036 Tel: +86-21-5258-9955 Fax: +86-21-5258-5505

Moxa Asia-Pacific:

Tel: +886-2-8919-1230 Fax: +886-2-8919-1231



© 2017 Moxa Inc. All rights reserved.

P/N: 1802000161011

Overview

The rugged VPort P16-1MP-M12 cameras provide an HD (720P, 1280 x 720) video image, and feature an H.264/MJPEG IP dome, giving them the versatility and ruggedness to excel in many different installations and environments for mobile IP video surveillance applications. In addition, the cameras are compliant with mandatory sections of EN 50155, covering operating temperature, power input voltage, surge, ESD, and vibration, as well as conformal coating and power insulation, making them suitable for a variety of industrial applications, and feature vandal-proofing (EN 62262 IK10), a -25 to 55°C or -40 to 70°C (T models) operating temperature, a rugged M12 Ethernet port, PoE power inputs, IP66 rain and dust protection, and day & night image capability.

Package Checklist


Moxa's VPort P16-1MP-M12 is shipped with the following items. If any of these items is missing or damaged, please contact your customer service representative for assistance.

		Temperature		Conformal	
Model	Lens	-25 to	-40 to		
		55°C	70°C	coating	
VPort P16-1MP-M12-CAM36	3.6 mm	\checkmark			
VPort P16-1MP-M12-CAM80	8.0 mm	\checkmark			
VPort P16-1MP-M12-CAM36-T	3.6 mm		~		
VPort P16-1MP-M12-CAM80-T	8.0 mm		\checkmark		
VPort P16-1MP-M12-CAM36-CT	3.6 mm	\checkmark		\checkmark	
VPort P16-1MP-M12-CAM80-CT	8.0 mm	\checkmark		\checkmark	
VPort P16-1MP-M12-CAM36-CT-T	3.6 mm		\checkmark	\checkmark	
VPort P16-1MP-M12-CAM80-CT-T	8.0 mm		\checkmark	\checkmark	

1 VPort P16-1MP-M12 (lens included)

Screw handle accessory package

Torx screw driver for attaching/detaching the upper case	4 sets of nut, gasket, and spring washer for mounting the camera	4 Nylock screws (10 mm) for mounting the top cover on the ceiling in a flush mount installation



- Quick Installation Guide
- Documentation and software CD (includes User's Manual, Quick Installation Guide, and Utility)
- Warranty card

NOTE Check the model name on the VPort's side label to determine if the model name is correct for your order.

NOTE This product must be installed in compliance with your local laws and regulations.

Features

- 1/2.7" HD progressive CMOS image sensor
- High image quality with WDR (wide dynamic range) and DNR (Digital Noise Reduction) supported
- Minimum illumination is up to 0.2 lux (color)
- Supports MJPEG and H.264 Dual Codecs
- Supports ONVIF Profile S for multiple video stream profiles
- Video stream up to 30 frames/sec at WXGA (1280 x 800) resolution
- Supports video quality configuration with fixed bit rate (CBR) and fixed quality (VBR)
- Video latency under 200 ms
- DynaStream[™] for network efficiency with dynamic frame rate change
- WXGA/720P/SVGA/ Full D1/ 4CIF/ VGA/ CIF resolution
- TCP, UDP, and HTTP network transmission modes
- Supports DHCP OPT66/67 for automatic configuration from TFTP server, making it easy to batch configure several units
- Supports RTSP streaming
- Support multicast (IGMP) video streaming
- Supports SNMP (V1/V2C/V3) for network system integration and management
- Supports QoS (ToS) for transmission priority
- Built-in web server for easy configuration
- Accessible IP filtering
- UPnP supported
- Complies with all EN 50155 mandatory test items*

*This product is suitable for rolling stock railway applications, as defined by the EN 50155 standard. For a more detailed statement, click here: www.moxa.com/doc/specs/EN 50155 Compliance.pdf

1 10/100BaseT(X) port with M12 D-code connector

- · IP66 rain and dust protection, with dehumidifying membrane
- PoE (Power-over-Ethernet, IEEE 802.3af) supported
- EN 62262 IK10 level vandal resistance
- -25 to 55°C (EN 50155, Class T1), or -40 to 70°C (EN 50155. Class TX) operating temperature for rolling stock environments
- CE, FCC, UL 60950-1
- Built-in tamper alarm and Video Motion Detection (VMD)
- Pre, Trigger, and post snapshot images supported
- Sequential snapshot images supported
- Supports SMTP and FTP for alarm message transmission
- Supports HTTP event server
- 5-year warranty

NOTE The VPort P16-1MP-M12 is designed for onboard environments, and should be used inside the car or train.

Product Description of the VPort P16-1MP-M12

Appearance



- Mounting screw (panel mount): 4 nylock M4 screws (40 mm) are included with the accessory to mount the VPort P16 on the wall or ceiling; the external length is about 20 mm after installation. The 4 mounting screws can work with the 4 sets of nut, gasket, and spring washer, or can be screwed directly into the screw holes.
- **NOTE** If the length of the mounting screws is insufficient for your installation environment, you may use longer M4 screws (not provided with the product), or contact your Moxa sales representative for customization service.
- Top cover mounting screws: 4 Nylock screws (10 mm) are included with the accessory for flush mounting the top cover on the ceiling.
- **Top cover:** The top cover can be removed for tuning the camera lens position.
- Lens: The VPort P16-1MP-M12 can be used with 2 different lenses with different focal lengths: 3.6 mm and 8 mm (Complete model names include "-CAMxxxxxxx". See page 2 for details).
- Dome cover: The VPort P16-1MP-M12 comes with a vandal-proof PC dome cover, which complies with EN 62262 (IEC 62262) class IK10.

NOTE The color of the dome cover can be customized based on your installation environment. Contact your Moxa sales representative for information about this customization service. However, keep in mind that the dome cover will decrease the amount of light that can be transmitted into the lens. The darker the dome cover, the greater the decrease of light transmittance.

Bottom View



 PoE & Etherent M12 connector: A 4-pin M12 D-code connecter for both PoE power supply (Mode A) and Auto MDI/MDI-X Ethernet connection.

PIN	ТХ	
1	TD+	2 3
2	RD+	
3	TD-	
4	RD-	1 4

NOTE To connect the VPort 16-M12 series to the network, use an Ethernet cable with a D-code M12 connector and an M12 PoE switch or RJ45 PoE switch.

SWITCH OF RJ45 POE SWITCH.	
M12 D-code to	M12 PoE Switch
M12 D-code cable	(e.g., TN-5508-4PoE)
0	
M12 D-code and	RJ45 PoE switch
RJ45 cable	(e.g., EDS-P510)
Q	

NOTE The power input rating of the VPort P16-1MP-M12 is 48V/0.35A, and the maximum power consumption is about 5 W.

NOTE The equipment is designed for installation inside a building, and is not intended to be exposed to the outdoors.

- Reset button: Loosen the screw and use a pointed stick, such as a toothpick, to push in the reset button to reboot to factory defaults.
 - > Reboot: press the button once and then release.
 - Factory default: press and hold the button for at least 90 seconds.

Top View without top cover and dome cover



- Calibration for tuning the horizontal lens position (0 to 350°): After tuning the horizontal lens position, mark the position with this calibration for future replacement or mass installations.
- 2 screws for fixing the horizontal lens position: There are 2 screws for fixing the horizontal lens position. A 5.5 kgf-cm torque is required for onboard environments.

Side view without top cover and dome cover



2 screws for fixing the vertical lens position: There are 2 screws for fixing the vertical lens position. The vertical lens position can be tuned from 0° to 80°. A 5.5 kgf-cm torque is required for onboard environments.


Hardware Installation

Step 1: Open and remove the upper case.

Use the security Torx to loosen the screws on the top of the camera casing.



Step 2: Use the installation sticker for drilling the holes (gray color for panel mounting, green color for flush mounting).





Step 3: Place the VPort P16 over the holes

Panel Mount

washers to fix the camera, and then connect the M12 Ethernet cable.



Flush Mount

Screw the hex nuts, gaskets, and Position the camera lens over the hole, and hide the VPort P16's body above the ceiling.



Step 4: Loosen the screws that fix the horizontal and vertical lens positions. Next, tune the camera lens position, and connect to the VPort P16's web console to view the video image. After the lens position is correct, fix the screws (5.5 kgf-cm torque is required).





Step 5: Fix the top cover to complete the installation.

Panel Mount

Re-screw the 4 top cover screws.



Flush Mount

Screw the 4 flush mount top screws (provided with the accessory) on the top cover.



- **NOTE** Because of the anti-vibration design, for onboard environments 8 kgf-cm torque is required for all mounting screws.
- **NOTE** The Nylock screws are designed to be used 2 or 3 times only. We recommend using new Nylock screws if the existing screws have been loosened and retightened 2 times.
- **NOTE** The 4 flush mount top cover screws can fix the VPort P16's top cover to ceilings that are 5 mm or less thick. You can provide the M4 screws yourself, or contact Moxa for special support if you require longer top screws.

Software Installation

Step 1: Configure the VPort P16's IP address

When the VPort P16 is first powered on, the POST (Power On Self Test) will run for a few moments (about 40 seconds). The network environment determines how the IP address is assigned.

Network Environment with DHCP Server

For this network environment, the unit's IP address will be assigned by the network's DHCP server. Refer to the DHCP server's IP address table to determine the unit's assigned IP address. You may also use the Moxa VPort and EtherDevice Configurator Utility (edscfgui.exe), as described below:

Using the Moxa VPort and EtherDevice Configurator Utility (edscfgui.exe)

 Run the edscfgui.exe program to search for the VPort. After the utility's window opens, you may also click on the Search button

😫 to initiate a search.

 When the search has concluded, the Model Name, MAC address, IP address, serial port, and HTTP port of the VPort will be listed in the utility's window.

List Server Firmware Co	onfiguration	Convert View Hel	р		
2 2 2 2 2 2 2 2	: 📤 \mid 💌				
Model	IP Address	MAC Address	Status	Name	Location -
VPort 56-2MP-CAM10X	172.19.16	00:90:E8:56:00:03			
VPort 56-2MP-CAM10X	172.19.16	00:90:E8:3E:A7:92			
VPort	172.19.16	00:90:E8:81:27:01		VPort	
VPort06	172.19.16	00:90:E8:06:01:01		VPort06	
VPort 354	172.19.16	00:90:E8:20:02:F3			
VPort36	172.19.16.5	00:90:E8:36:01:01			
IKS-6526-SB	172.19.16	00:9E:0E:86:52:61		Managed	
	172.19.16	00:0A:19:03:64:13		VPort 364	
EDS-408A-MM-SC	172.19.16	00:90:E8:0D:66:73		Managed	Switch L
VPort06	172.19.16	00:90:E8:06:06:06		VPort06	
	172.19.16	00:90:E8:2D:2C:A8			1
	172.19.16	00:0A:19:74:12:D6		VPort 461	
VPort P06HC-1MP-M12		00:90:E8:06:0C:01		VPort P06	
	172.19.16	00:0A:19:74:12:13			
	172.19.16	00:90:E8:23:F3:D2			
	172.19.16	00:90:E8:2F:6F:14		VPort 36-1	
	172.19.16	00:90:E8:3F:82:9A		VPort 461	
	172.19.16	00:90:E8:28:0A:49		VPort 461-T	
	172.19.16	00:90:E8:20:9D:E1			
VPort 364A-T	172.19.16	00:90:E8:32:DE:BA			
4					•
Ready					

3. Double click the selected VPort, or use the IE web browser to access the VPort's web-based manager (web server).

Non DHCP Server Network Environments

If your VPort P16 is connected to a network that does not have a DHCP server, then you will need to configure the IP address manually. The default IP address of the VPort 16-M12 is 192.168.127.100 and the default subnet mask is 255.255.255.0. Note that you may need to change your computer's IP address and subnet mask so that the computer is on the same subnet as the VPort.

To change the IP address of the VPort manually, access the VPort's web server, and then navigate to the **System Configuration** \rightarrow **Network** \rightarrow **General** page to configure the IP address and other network settings. Check the **Use fixed IP address** to ensure that the IP address you assign is not deleted each time the VPort is restarted.

Step 2: Accessing the VPort P16's web-based manager

Type the IP address in the web browser's address input box and then press enter.

Step 3: Install the ActiveX Control Plug-in

A security warning message will appear the first time you access the VPort's web-based manager. The message is related to installing the VPort AcitveX Control component on your PC or notebook. Click Yes to install this plug-in to enable the IE web browser for viewing video images.

nternet Explorer - Security Wa	rning 🔀
Do you want to install this softwa	are?
Name: MOXA VPort A Publisher: Moxa Networki	ActiveX Plugin (VPort 16-1MP-M12) ng Co., Ltd.
S More options	Install Don't Install
	can be useful, this file type can potentially harm oftware from publishers you trust. <u>What's the risk?</u>

NOTE For Windows XP SP2 or above operating systems, the ActiveX Control component will be blocked for system security reasons. In this case, the VPort's security warning message window may not appear. Users should unlock the ActiveX control blocked function or disable the security configuration to enable the installation of the VPort's ActiveX Control component.

Step 4: Access the homepage of VPort P16's web-based manager.

After installing the ActiveX Control component, the homepage of the VPort 16's web-based manager will appear. Check the following items to make sure the system was installed properly:

- 1. Video Images
- 2. Video Information



Step 5: Access the VPort's system configuration.

Click on **System Configuration** to access the overview of the system configuration to change the configuration. **Model Name**, **Server Name**, **IP Address**, **MAC Address** and **Firmware Version** appear in the green bar near the top of the page. Use this information to check the system information and installation.

For details of each configuration, check the User's Manual on the software CD.

MOXV	VPort P16-1	MP-M12		www.moxa.col
del Name : VPort P16-1MP4812 Iddress : 172.19.16.7	Server Name : V74 MAC Address : 00	of P16-199-012 P Camera 90.68:19:19:16 Firm, Version : 1.	0 Bulls : 14050812	
tome Main Menu DoerView Potiles	the name of the	System Configuration pages. A brid page you would like to open.	f description of each configuration group is given below. Click on a plus sign in the left pane to expand a	group, and then click on
🖲 🧰 System	Category	Item	Description and Contest	
😑 Network	Profiles	Configuration	Configure ONVIF Profile settings	
🗀 Video		General	Setting Host Name and Date/Time	
Streamnin		Account	Administrator, User and Demo Account Privileges Management	
* Event		System Log	System Log and operation information	
Actions	System	System Parameter	System parameters information and Import/Export function	
	Firmware Upgrade	Remote Firmware Upgrade		
😑 Test (Roservod)		Factory Default	Reset to Factory Default	
		Reboot	Device will reboot for restarting system	
lest viewed with IE 9 or hove with resolution of		General	The IP network settings of this VPort	
280x1024		DONS	Configure DDNS	
		Universal PnP	Enable UPnP function	
		ToS	Configure ToS(Type of Service)	
	Network	Accessible IP	Set up a list to control the access permission of dients by checking their IP address	
		SNMP	Configure the SNMP settings	
		Modbus/TCP	Enable Modbus/TCP function	
		Telnet	Configure Telnet	
		LLDP	Configure LLDP	
		Image Setting	Configure the information of video image	
	Video	Camera Setting	Configure the attributes of video image	
	******	Privacy Mask	Configure the Privacy Mask settings	
		Video Encoder	Set up the Encode Standard(MIPEG or H.264), Size (Resolution), FPS, Quality and Multicast settings	

Wiring Requirements



ATTENTION

Safety First!

Be sure to disconnect the power cord before installing and/or wiring your Moxa VPort P16-1MP-M12.


Calculate the maximum possible current in each power wire and common wire. Observe all electrical codes dictating the maximum current allowable for each wire size.

If the current goes above the maximum ratings, the wiring could overheat, causing serious damage to your equipment.

You should also pay attention to the following:

- Use separate paths to route wiring for power and devices. If power wiring and device wiring paths must cross, make sure the wires are perpendicular at the intersection point.
- You can use the type of signal transmitted through a wire to determine which wires should be kept separate. The rule of thumb is that wiring that shares similar electrical characteristics can be bundled together.
- Keep input wiring and output wiring separated.
- It is strongly advised that you label wiring to all devices in the system when necessary.

Dimensions (unit = mm (inch))



Specifications

Camera	
Sensor	1/2.7" Progressive CMOS
Lens	3.6 and 8 mm fixed focal length
Angle of view	3.6 mm, F1.6: Diagonal 120°, Horizontal 96°,
	Vertical 56°
	8.0 mm, F1.8: Diagonal 48°, Horizontal 38°,
	Vertical 24°
Camera lens angle	PAN 350°, TILT 0 to 80° (controlled manually)
Illumination (low light	Color: 0.2Lux@F1.2,
sensitivity):	B/W:0.05Lux@F1.2,
ICR Control (for day &	Auto
night)	
Synchronization	Internal
White Balance	ATW/ AWC (range: 3200 to 10000°K)
Auto Electronic Shutter	1/30 to 1/25000 sec
S/N Ratio	50 dB (Gamma, Aperture, AGC, OFF; DNR ON)
DNR	Built-in
WDR	Level 1-8
AGC Control	2X, 4X, 8X, 16X, 32X, 64X
Flickerless Control	Automatic/50 Hz/60 Hz
Black Level Control	High/Medium/Low
Auto Exposure	Level ±5
Image Rotation	Flip, Mirror, and 180° rotation
Image Setting	Manual tuning with saturation, sharpness, and
	contrast

Video							
Video Compression		H.264 (ISO/IEC 14496-10) or MJPEG					
Video Output		Via Etherne	•				
Video Strea				and 1 MJPEC	i)		
Video Res	olution and	FPS (Frame	per second)	:			
l	NT	60					
	NT Size	Max. FPS		AL Max. FPS			
	176 x 112		Size	25			
		30	176 x 144	-			
CIF VGA	352 x 240	30	352 x 288	25			
	640 x 480	30	640 x 480	25			
4CIF	704 x 480	30	704 x 576	25			
Full D1	720 x 480	30	720 x 576	25			
SVGA	800 x 600	30	800 x 600	25			
HD	1280 x 720	30	1280 x 720	25			
WXGA	1280 x 800	30	1280 x 800	25			
Network Protocols		 bandwidth transmissions DynaStream[™] supported for automatic frame rate adjustment 3 configurable privacy mask areas Adjustable image size and quality Timestamp and text overlay OSD (On screen Display) position adjustable Maximum of 5 simultaneous unicast connections TCP/IP, UDP, HTTP, SMTP, NTP, DNS, DHCP, UPnP, RTP, RTSP, ICMP, QoS, IGMPv3, SNMPv1/v2c/v3, DDNS, TFTP, ARP, DHCP, OPT66/67					
Ethernet	Ethernet		1 10/100BaseT(X) isolated Ethernet port, 4-pin M12 Dcode female connector				
Power Re	quirements						
Input		Power-over-Ethernet (IEEE 802.3af)					
Consumption		Maximum 5 W					
Physical (Characteristi	cs					
Housing		Metal and glass, PC dome cover, IP66-rated					
Dimensions		125 x 125 x 120.7 mm (5.6 x 5.6 x 4.8 in)					
Weight		810 g					
Installation		Surface (ceiling) or flush (recessed) mounting					
Environm	ental Limits						
Operating Temperature		Standard Models: -25 to 55°C (-13 to 131°F) Wide Temp. Models: -40 to 70°C (-40 to 158°F)					
Storage Temperature		-40 to 85°C (-40 to 185°F)					
Storage Le	inperatare						
Ambient Re Humidity			non-condensir	ng)			

Regulatory Approvals				
Safety	UL 60950-1			
EMI	I FCC Part 15, CISPR 32 Class A			
EMS	IEC 61000-4-2 ESD: Contact: 6 kV; Air: 8 kV IEC 61000-4-3 RS: 80 MHz to 1 GHz: 20 V/m IEC 61000-4-4 EFT: Power: 2 kV; Signal: 2 kV IEC 61000-4-5 Surge: Power: 2 kV; Signal: 2 kV			
	IEC 61000-4-6 CS: 10 V			
Rail Traffic	IEC 61000-4-8 EN 50155*, EN 45545-2			
	for rolling stock railway applications, as defined			
by the EN 50155 standar	d. For a more detailed statement, click here: <u>cs/EN_50155_Compliance.pdf</u>			
Shock	IEC 61373			
Freefall	IEC 60068-2-32			
Vibration	IEC 61373			
Vandal resistance	IEC 62262, IK10 level			
Salt Spray Test	ASTM B117			
	s website for the most up-to-date certification			
MTBF (mean time betw	veen failures)			
Time	Ground Benign: 1,602,553 hours Ground Mobile: 179, 703 hours			
Standard	Telcordia TR/SR			
Warranty				
Warranty Period	5 years			
Details	See www.moxa.com/warranty			
Alarm Features				
Intelligent Video: Car	nera tamper			
	on: 3 independently configurable areas			
Scheduling: Daily repeat timing schedule				
 Imaging: JPEG snapshots for pre/trigger/post alarm images Custom Alarms: HTTP event servers for setting customized alarm actions 				
 Email/FTP Messaging: Automatic transfer of stored images via email or FTP as event-triggered actions 				
Pre-alarm Buffer: 12 MB video buffer for JPEG snapshot images				
Security				
Password: User level password protectionFiltering: By IP address				
Encryption: HTTPS, SSH				
Minimum Viewing System Requirements				
CPU: Pentium 4, 2.4 GHz				
2	Memory: 512 MB of memory			
OS: Windows XP/2000 with SP4 or above, Windows Vista, Windows 7				
Browser: Internet Ex				
Multimedia: DirectX 9				
Software Development				
VPort SDK PLUS	Includes CGI commands, ActiveX Control, and API library for customized applications or system integration for third-party developer			
Standard ONVIF Profile S				